


How to update your Music Finder – CVP605/609

- Select the Music Finder file for your instrument from the list and save it to an appropriate type of USB storage device for your Clavinova.
- Insert the device into the Clavinova.
- Call up the Music Finder display via [Menu] - [Music Finder].



- Touch the [Load] icon (outlined above) to call up the File Selection display.
- Locate the Music Finder file on your USB device and select [REPLACE] to replace the current Music Finder records with the new version.

Note: The original Music Finder file is permanently stored on your instrument's PRESET page.